DATE: TO:



CERTIFIED



LOW-NOISE DIESEL-POWERED AC GENERATOR

DG450UMI-QD (200/400)

SPECIFICATIONS

CHAPTER 1: GENERAL CHAPTER 2: EQUIPMENT SPECIFICATIONS ATTACHED DRAWINGS

- APPEARANCE
- GENERATOR WIRING
- ENGINE WIRING

SHINDAIWA Corporation

6-2-11, Ozuka-Nishi, Asaminami-Ku, Hiroshima, 731-3167, Japan

Chapter 1 General

1. Standards

- The designs and the productions are in conformity with:
- (1) Japan Industrial Standards
- (2) Electricity Academy Corporation Electricity Standard Research Association Standard (JEC)
- (3) Japan Electric Industries Corporation Standard (JEM)
- (4) Japan Combustion Generating Equipment Corporation
- (5) Ministry of Construction (Low Noise Type Construction Machinery Standard)
- (6) Ministry of Construction (Construction Machinery Gas Emission Regulation Standard)
- 2. Design Conditions
 - (1) Installation Place: Inside/Outside
 - (2) Ambient Temperature: -15-+40°C
 - (3) Humidity: Less than 80%
 - (4) Altitude: Less than 300meter (Sea Level)
- 3. Test and Check

The test shall be done for the complete workable unit of Diesel Engine and Portable Generating Unit. (1) Checking Items

- a) Insulation and Dielectric Tests
- b) Starting
- c) Protection Devices Working Test
- d) Voltage Deviation and Speed Variation: 1/4, 2/4, 3/4 and 4/4 Load
- e) Load Test: 4/4 Load 30 minutes
- 4. Painting
 - (1) Painting specifications and color are the manufacturer's standard

SPECIFICATION

Model		DG450UMI-QD	
Item			
AC generator	Brushless, 3-Phase synchronous AC generator		
Frequency	(Hz)	50/60	
Rated output	(k VA)	37/45	
	(kW)	29.6/36.0	
Rated voltage	(V)	200/220, 400/440	
Rated amperage	(A)	107/108, 53.5/59	
Number of polarity		4	
Rated power factor	—	0.8 (lagging)	
	(V)	100/110	
Single Phase output	(A)	Terminal 75, 38x2	
	(A)	Receptacle 15Ax4	
Engine Model	_	ISUZU BB-4JG1T	
Туре	_	4-cycle,water-cooled,direct injection type	
Air induction system		Exhaust turbocharger	
Number of cylinder	_	4	
Bore x stroke	(mm)	95.4x107	
Displacement	(L)	3.059	
Rated output	(kW)	35.4/42.6	
Rated revolution speed	(min⁻¹)	1500/1800	
Fuel	_	Diesel fuel (JIS K2204,class 1 to 3)	
Fuel consumption Note1	(L/hour)	6.6/7.9	
Lubricating oil type	_	Class CD or better, SAE30	
Lubricating oil capacity	(L)	10 (Effective 3)	
Lubricating oil consumption Note2	(L/hour)	0.018	
Coolant capacity	(L)	13	
Battery		95D31R	
5-hour capacity	(Ah)	64	
Fuel tank capacity	(L)	124	
Equipment dimension L×W×H	(mm)	1770×920×1350	
Mass Dry weight		1130	
Amount weight	(kg)	1260	

Note1, 2: The indicated values were obtained under normal operating condition at 75% load. Use the numerical value as reference.

Chapter 2 Equipment Specifications

- Diesel Engine Model: ISUZU BB-4JG1T Displacement: 3.050 L Rated Output/Rated Speed: 35.4kW {48.10PS}/42.6kW{57.9PS} : 1500/1800min⁻¹{rpm} Fuel: Diesel Fuel ASTM No. 2 or Equivalent Fuel Filter: Paper Filter Automatic Air Extraction: Standard Accessory External Fuel Changeover: Standard Accessory Battery: 95D31R (12V-64AH)
- 2. 3-Phase Synchronous Generator
 - 1) Alternator Model: Rotating Field, Self-Ventilation (JCO), Protection (JP20) Output: 37.0/45.0kVA (29.6/36.0kW) Rate: Continuous Voltage: 400/440V Current: 53.4/59.0A Frequency: 50/60Hz Speed: 1500/1800min⁻¹ Pole: 4 Poles Power Factor: 0.8 Lagging Exciting Method: Brushless, AC Exciter Wiring: Star, 3-Phase 4-Wire Insulation: Stator Wiring Class F : Rotor Wiring Class B Standard: JIS, JEM, JEC
 - 2) Characteristic

Voltage Deviation: Less than $\pm 1.0\%$ for the nominal value : Transient Values to be less than 20% (100%kVA, Power Factor 0.4) Over-speed Endurance: 2 minutes of120% of the rated speed Wave Distortion: Less than 2% (3-Phase, Line to Line, No Load) Generator Efficiency: More than 85% Insulation Resistance: More than 5MΩ Dielectric Insulation: 1500V for 1 minute or 1800V 1 second

- 3. Structure
 - Beds (bottom columns) and Vibration Proof Device Alternator is coupled directly with engine and they are installed on the bed through vibration proof device (Rubber Pad and Angle).
 - 2) Low Noise Sound-Proof Enclosure (Bonnet) The structure is that the inside of the bonnet is sound-proof treated and you can lift up the alternator and the engine together with the beds by using a lifting lug. Sound Level: 51/53dB (A)/7m (No Load 1500/1800 min⁻¹)
 - 3) Fuel Tank

The fuel tank is made of steel and incorporated with the electric type gauge. Capacity: 124L

- 4. Control Devices, Gauges and Protection Devices
 - 1) Control Device Breaker: Circuit Breaker (Rate 600V 125A) : Circuit Breaker (Rate 600V 75A) Exciter Circuit: Automatic Voltage Regulator (F/V Characteristic) Current Leakage Shut Off Device: 30mA 0.1 second 2) Gauges (Displays) AC Volt Meter: 0-600V AC Ampere Meter: 0-75/150A Frequency Meter: 45-65Hz Hour Meter: 9999.9Hr Oil Pressure Gauge Water Temperature Gauge Preheat Lamp Disorder Display Lamps: High Water Temperature, Low Oil Pressure, Insufficient Charging Voltage Adjuster: Adjustable Range; Below-10%- and over +5% Panel Light Emergency Stop Button
 - 3) Protection Device


Item	Set Value	Display	Trip	Shut-Down
Low Oil Pres.	98.1kPa	\bigcirc	-	0
High Water Temp.	105°C	0	-	\bigcirc
Insufficient Charging	-	0	-	-
Over Current (Thermal relay)	120%	_	0	-
Current Leakage	30mA 0.1sec.	0	\bigcirc	-

4) Output Terminals Plate


R, S, T and O output terminals, 4 (four) receptacles of auxiliary power 100/110V 15A x 4 and 2 (tow) 37.5A 1-Phase output terminal set

- 5. Dimension and Weight Length: 1770mm Width: 920mm Height: 1350mm Dry Weight: 1130kg Outfitted Weight: 1260kg
- Accessories Grounding Rod: 1 piece Fuse: 10A 1 piece Instruction manual Manual, engine


• APPEARANCE




RIGHT SIDE VIEW




LEFT SIDE VIEW



TOP VIEW






NO.	Name	Description of function	
1	3-phase circuit breaker	Turns the power supply to load equipment ON (closed) and	
		OFF (open).	
2	1-Phase circuit breaker	Turns the power supply to load equipment ON (closed) and	
		OFF (open).	
3	Voltage meter	Indicates voltage.	
4	AC ampere meter	Indicates phase current.	
5	Frequency meter	Indicates electricity frequency.	
6	Earth leakage relay	Detects electric leakage in the 3 phase,4wire output, and turns	
		the circuit breaker OFF when activated	
7	Panel light	Illuminates control panel surface and	
		Indicates generated electricity when the engine is in operation	
		and generating.	
8	Voltage adjustment dial	Used to adjust voltage.	
9	Volt meter change over switch	Used to change the display voltage between phases	
10	Warning indicator : NOTE	Lights when an equipment malfunction occurs.	
11	Coolant temperature gauge	Indicates temperature of the engine coolant.	
12	Oil pressure. gauge	Indicates lubricating oil pressure.	
13	Fuel meter	Indicates remaining fuel.	
14	Hour meter	Indicates operating hours of the generator unit.	
15	Emergency stop switch	When the switch is pressed, stops an engine operation.	


NO	Name	Description of function	
16	Pre-heat indicator	The indicator lights when the key switch is set to the [ON]	
		position, and starts pre-heating.	
17	Starter switch	OFF: stops engine operation.	
		ON: supplies electricity for control operation, and starts	
		pre-heating.	
		START: starts an engine operation	
18	Throttle lever	Low idling or rated speed selecting lever.	
19	Frequency (Speed) adjusting knob	Used to fine adjustment of frequency	
20	Frequency select switch	Select the rated speed of engine.	

NOTE


High water temp. Low oil press. Charge fault



• GENERATOR WIREING



ENGINE WIRING



MENO